



It is very important for you to follow these installation instructions carefully. Adhesive failure may occur should they be ignored.

TOOLS YOU'LL NEED

- 1 PAIR OF TWEEZERS
- 1 PAIR OF LATEX GLOVES

If you don't have these, stop here, and go to your local "Auto Parts" store and get them. You'll be glad you did.

PART 1 CLEANING PROCEDURE

- 1) Armor All is the #1 enemy of adhesion. Keep that in mind!
- 2) First dilute several drops of liquid dish detergent in a mug with a little water.
- 3) Once diluted use a tooth brush to scrub the indentation. Scrub it well until it lathers.
- 4) Rinse indentation with water until all soap is completely removed. Keep towel underneath to catch dripping water if any.
- 5) Repeat process a second time.
- 6) Now wait a couple hours for dash to dry.

PART 2 INSTALLATION

- 1) Wearing a pair of latex gloves, detach the Airbridge insert and hold it either with the tweezers or by your index and thumb fingers (assuming you're wearing the latex gloves), hold it by the edge and position it over the "Airbridge".
- 2) Once you have it well aligned over the Airbridge, let it make contact with surface.
- 3) Now you can lightly press on it to make full contact.
- 4) We highly suggest you to perform the "Recommendation" below before installing this insert.

PART 3 RECOMMENDATION

The Airbridge itself it is made of a pretty slippery plastic which doesn't allow much for adhesion. Therefore for better adhesion we suggest you to do the following.

- 1) Use a fine grit sand paper to sand surface of Airbridge to produce a coarser surface in which the "insert's" adhesive will have better bond. Very little sanding is necessary, you'll see the change from shiny surface to semi-dull surface. That's when you know the surface is ready for application. Airbridge insert may come loose without any sanding.
- 2) Prior to installation you must use a pair of latex gloves. Do Not allow your finger prints to touch adhesive side of insert. Finger prints are saturated with oils and will transfer to adhesive should your fingers make contact with it, thus compromising the adhesive.

PART NO. 156182 SHEET 1 OF 1



DATE	REVISION	AUTH	DR
4/16/2008			

INSTALLATION INSTRUCTIONS

PART NO. 156182 SHEET 1 OF 1