




**NOTE:** Install only on a cold engine.

Underneat the throttle body there are two coolant lines (one on the bottom left and one on the bottom right sides of the throttle body). One line comes from the radiator and the other line comes from the intake manifold. Remove the lines where they enter the throttle body and “mate” them together with the by-pass tube. Secure with provided clamps.

**CAUTION:** This product is strongly NOT recommended or needed for vehicles in cold climates or where ambient air temperatures reach near freezing.

				PART NO.	305018	SHEET 1 OF 1
--	--	--	--	----------	--------	--------------

	DATE	REVISION	AUTH	DR	<b>INSTALLATION INSTRUCTIONS</b>	
	9/15/2006					
				PART NO.	305018	SHEET 1 OF 1