



It is very important for you to follow these installation instructions carefully. Adhesive failure may occur should they be ignored.

**TOOLS YOU'LL NEED**

- 1 PAIR OF TWEEZERS
- 1 PAIR OF LATEX GLOVES

If you don't have these, stop here, and go to your local "Auto Parts" store and get them. You'll be glad you did.

**PART 1 CLEANING PROCEDURE**

- 1) You may clean the grooves with a Q-tip wet in 91% Alcohol.
- 2) Slide the wet Q-tip through, making sure all the dirt is removed.
- 3) Several Q-tips will be needed for this procedure.
- 4) Clean both Fuel Rail covers before installation.

**PART 2 INSTALLATION**

- 1) Place Fuel Rail cover on a table, make sure room is well lighted.
- 2) Detach one letter with tweezers and carefully attach the end of the letter inside the groove and slide the remaining portion of the letter inside the groove.
- 3) Once the letter is completely inside the groove, press it with your finger to make full contact with surface
- 4) Repeat process for each letter until done.

PART NO. 306102 SHEET 1 OF 1



DATE	REVISION	AUTH	DR
4/16/2008			

**INSTALLATION INSTRUCTIONS**

PART NO. 306102 SHEET 1 OF 1